

INSTRUCTIONS

Before using your camera, read this manual carefully to ensure correct use.

PREPARATIONS

BASIC OPERATIONS

ADVANCED TECHNIQUES

CAMERA MAINTENANCE



Thank you for purchasing an Olympus camera. Before you start to use your new camera, please read these instructions carefully to obtain optimum performance and a longer service life from the unit.


WARNING




KEEP THE BATTERIES AWAY FROM FIRE
NEVER TRY TO DISASSEMBLE, RECHARGE
OR SHORT CIRCUIT BATTERIES.

NEVER ATTEMPT TO DISASSEMBLE THE
CAMERA; IT CONTAINS A HIGH-VOLTAGE
CIRCUIT.

IF THE INTERNAL PARTS OF THE CAMERA
ARE EXPOSED DUE TO DROPPING OR
DAMAGE, REMOVE THE BATTERIES
IMMEDIATELY TO PREVENT FURTHER
USAGE.





- Before using your camera, read this manual carefully to ensure correct use.
- We recommend that you take test shots to get accustomed to your camera before taking important photographs.

MAIN FEATURES

- An easy-to-use fully automatic camera with a leather-like touch.
- Built-in 38mm - 105mm approx. 3X zoom lens.
- Quartz date or time imprinting.
- Weatherproof ■ Remote control (optional).
- Versatile, easy-to-use functions include spot metering, night scene mode, as well as various flash modes.

Symbols used in this manual:

- | | | |
|--------------------|-----------------------|----------------------|
| ① Incorrect | ④ Operation order | ⑦ Indicator blinking |
| ② Next operation | ⑤ Automatic operation | ⑧ Attention |
| ③ Manual operation | ⑥ Indicator on | ⑨ Depress halfway |

Product shown in pictures and illustrations may be slightly different from the actual unit.

PREPARATIONS

Names and functions of parts	6
Viewfinder display/LCD panel	8
Diopter adjustment	9
Using the strap	9
Outline of operations	10
Loading the battery	13
Checking the battery	14
Points to remember	15

BASIC OPERATIONS


Loading the film	17
Taking pictures	20
Using the focus lock	25
After Shooting	27
Unloading the film	28

ADVANCED TECHNIQUES

Using the flash modes	29
Auto (Auto Flash)	31
Auto-S (Redeye-Reducing Flash)	32
OFF (Flash Override)	33
FILL-IN (Forced Activation)	34
<input checked="" type="checkbox"/> Night Scene	35
<input type="checkbox"/> Spot	36
Selftimer.....	37
Remote Control (optional)	38
Correcting the data	40
Printing the date and time	42

CAMERA MAINTENANCE


Questions and answers	43
Care and storage	44
Caring for your weatherproof camera.....	47
Battery handling	49
Remote control (optional) handling	51
Troubleshooting	52
Specifications	59



NAMES AND FUNCTIONS OF PARTS


- ① Zoom lever (See p. 21.)
Zooms In — telephoto.
Zooms out — wide-angle.
- ② Shutter release button (See p. 16.)
- ③ Selftimer/remote control button (See p. 37/38.)
- ④ Flash mode button (See p. 29.)
- ⑤ LCD panel (Date/time indicator) (See p. 8.)
- ⑥ Flash*
- ⑦ Selftimer indicator
- ⑧ Strap eyelet
- ⑨ Viewfinder
- ⑩ Light sensor*
- ⑪ Lens barrier
- ⑫ Autofocus windows*
- ⑬ Power switch
- ⑭ Lens*

☆ Do not soil as this can cause blurred pictures.
Wipe clean with a soft cloth.



- ⑮ Quartzdate mode buttons (See p. 40.)
- ⑯ Panorama lever (See p. 29)
- ⑰ Diopter adjustment dial (See p. 9.)
- ⑱ Viewfinder (See p. 8.)
- ⑲ Orange lamp
- ⑳ Green lamp
- ㉑ Film window
- ㉒ Back cover
- ㉓ Mid-roll rewind button (See p. 28.)
- ㉔ Tripod socket
- ㉕ Battery compartment cover
- ㉖ Back cover release

VIEWFINDER DISPLAY/LCD PANEL



Viewfinder Display

- ① Close-up correction marks
At a close distance, your subject must be positioned within the close-up correction marks.
- ② Orange lamp
Lights when the flash is ready to fire.
Blinks while the flash is recharging.
- ③ Green lamp
Lights when the subject is in focus.
Blinks when the subject is not in focus.

④ Autofocus mark

Position your subject within the autofocus mark.

LCD Panel

- ⑤ Date/time indicator
- ⑥ Exposure counter (See p. 19.)
- ⑦ Battery check (See p. 14.)
- ⑧ Spot (See p. 36.)
- ⑨ Selftimer/remote control (See p. 37/38.)
- ⑩ Flash modes (See p. 29.)

Note:


The LCD panel does not actually display all indication simultaneously as shown.

DIOPTER ADJUSTMENT

To Adjust the Viewfinder to Compensate for Near-and Far-sighted vision


Turn the diopter adjustment dial until the viewfinder display becomes clear.

Turn to the right if you are far-sighted or to the left if you are near-sighted.







USING THE STRAP

Attaching the strap.







OUTLINE OF OPERATIONS

Basic Shooting Procedures



1. Load a battery (p. 13).
2. Open the back cover (p. 17).
3. Load the film (p. 17).
(Use of ISO 400 film is recommended.)
4. Close the back cover. The film automatically advances to the first frame (p. 19).





5. Turn the power switch ON (p. 19).
The lens barrier will open automatically.

6. Make sure the exposure counter on the
LCD panel reads "1" (p. 19).



7. Press the zoom lever for telephoto or
wide-angle photography (p. 21).

8. Place the autofocus mark on the
subject you want to photograph (p. 22).



9. Depress the shutter release button halfway to make sure the green lamp lights (p. 22).



10. Depress the shutter release button fully to take a picture (p. 23).



11. When the film reaches the end, it will automatically rewind (p. 28).

12. Open the back cover to remove the rewound film (p. 28).

LOADING THE BATTERY




1. After turning the power switch OFF, push OPEN **①** to open the battery compartment cover **②**.
Turn the power switch OFF and close the lens barrier when replacing the batteries.




2. Insert the new battery correctly as shown and close the battery compartment cover tightly.
 - Use a 3 V lithium battery (DL 123A, CR123A, or equivalent.)
 - About 15 rolls of film can be used with one new battery. (p. 43)

Read "Battery Handling" on page 49.

CHECKING THE BATTERY


Turn the power switch ON. Check the remaining battery power.



Display	Meaning
 lights (and turns off automatically).	Battery is OK. You can shoot.
 blinks and other indicators on the LCD panel are displayed normally.	Battery power is low and battery should be replaced
 blinks and other indicators on the LCD panel go out.	Battery is dead and should be replaced immediately.

Note: Keep spare battery on hand when going on a long trip a wedding or when using the camera in cold weather. Adjust the data of the Quartzdate every time the battery is replaced.

POINTS TO REMEMBER





Hold the Camera Correctly.

1. Correct.
Hold the camera firmly with both hands while keeping elbows at sides to prevent the camera from shaking.
2. Correct.
In the vertical position, hold the camera with its flash positioned at the top.
3. Incorrect.

Caution:

keep your fingers and the strap away from the lens, lens barrier, autofocus windows and flash. (See p. 6)



Proper Shutter Release.

Practice before loading the film.

1. Depress the shutter release button halfway to lock the focus.


Make sure.

The green lamp next to the viewfinder lights.

2. Depress the shutter release button fully to release the shutter and take the picture.

Cautions:

- Press the shutter release button gently.
- Avoid shaking the camera when pressing the shutter release button to prevent blurry pictures.




LOADING THE FILM

1. Slide the back cover release upward to open the back cover.


Do not touch the inside of the camera, especially the lens. If there is dust or dirt on the lens, remove it with a blower brush.

2. Insert the film cartridge, making sure the film is lying flat.

Note: Use of ISO 400 film is recommended.
When using non-DX-coded film, use ISO 100 film.




- A. Correct.
Make sure the film is lying flat before closing the back cover.



- B. Incorrect.
If the film is not lying flat as shown, the film may not advance to the first frame.


Caution:
Do not touch the plastic parts near the take-up spool.



3. Align the film leader with the mark ①, and close the back cover.
The film automatically advances to the first frame.

Make sure

The film does not overlap any of the positioning guides ② shown on the left.



4. Turn the power switch ON.

Make sure

The exposure counter on the LCD panel reads 1.

Note:

If E blinks in the exposure counter, as shown on the left, the film is improperly loaded. Reload the film.

TAKING PICTURES





1. Turn the power switch ON.


Make sure

The lens extends slightly, the flash pops up, and the LCD panel activates.

When the flash is held down, the two indicators next to the viewfinder blink.
The camera will not activate.
The display also goes out.

Release the flash to reactivate the camera.





2. Aim the camera at your subject. Use the zoom lever for telephoto or wide angle photography.

How to Use the Zoom Lever:

Telephoto:


Pull the lever to the "T" side to zoom in.

Maximum telephoto focal length: 105 mm

Wide angle:

Push the lever to the "W" side to zoom out.

Maximum wide-angle focal length: 38 mm





3. Position the autofocus mark on your subject.


① Autofocus mark

⊗ Do not look directly at the sun through the viewfinder.

4. Depress the shutter release button halfway to adjust the focus.


Ⓢ Make sure

Focus has been correctly adjusted and the green lamp lights. Exposure also will be adjusted automatically.



5. Depress the shutter release button fully to take the picture.

The film automatically advances to the next frame.



Working Distance

The focus range of the camera is 0.6 m (2 ft) to ∞ (infinity).

- When the subject is closer than 0.6 m (2 ft), the shutter will not release. (The green lamp blinks.)
- When the subject is extremely close to the camera, the subject will be out of focus although the shutter releases.

Close-up Correction


- ① Picture frame
- ② Close-up correction marks
- ③ Image area of picture at 0.6 m (2 ft)

The viewfinder's picture frame shows the area that can be shot for subjects at ∞ . However, the picture area will move lower in the viewfinder as you get closer to the subject. At 0.6 m (2 ft), the shaded area is the actual available image area. In this case, the subject should be positioned below the close-up correction marks.



USING THE FOCUS LOCK To Avoid Taking Out-of-focus Pictures


When the main subject is not within the autofocus mark. Use the focus lock.

The autofocus mark must be positioned on the subject in this case, the camera will focus on the background behind the subjects and the subjects will be out of focus.





① Autofocus mark



1. Position the autofocus mark  on your subject and press the shutter release button halfway.

Make sure

The green lamp lights.




2. Reposition your subjects in the picture frame while keeping the shutter release button depressed halfway. Then press the shutter release button fully.

Difficult Autofocus Subjects

- Glossy or reflective surfaces
- Black objects
- Subjects behind glass or wire mesh
- Flames, smoke, etc.
- Sunlight or excessively bright light within the picture area

In such situation as the above, use the focus lock by focusing on a different subject at a similar distance. Then reposition the correct subject in the picture frame.

AFTER SHOOTING






1. When the power switch is turned OFF, the lens and flash will retract automatically.

The display goes out.

2. Close the lens barrier.

UNLOADING THE FILM




The camera automatically rewinds the film when you reach the end of a roll. After the motor stops and **E** starts blinking on the LCD panel, open the back cover and remove the film.


Notes:

- The number of exposures remaining decreases during rewinding.
- The final number of exposures may sometimes exceed the number of exposures specified on the film.

Rewinding the film before the end of the roll

Press the mid-roll rewind button gently with your nail, etc. Do not use an instrument with a sharp tip.





USING THE FLASH MODES


This camera has five flash modes. Select the flash mode according to your shooting conditions and needs.

How to select the flash mode:

As you press the FLASH mode button, the mode switches as shown on p. 30. The selected flash mode is displayed on the LCD panel.

- ⊗ Do not discharge flash too close to eyes of people or animals.

LCD Panel Display



AUTO mode:

Automatically fires in low-light and backlit conditions
(p. 31)

AUTO-S mode:

Significantly reduces the phenomenon of "red-eye"
(when a subject's eyes appear red in flash photos)
(p. 32)

OFF mode:

The flash does not fire. (p. 33)


FILL-IN mode:


Fires regardless of available light, (p. 34)



Lights the subject in the foreground with a
nightscene in the background. (p. 35)

Note:

- In the Auto, Auto-S Flash, and  modes, the flash strength is automatically controlled to prevent pictures from being overexposed even when the subjects are close.



AUTO (Auto Flash)

In the Auto Flash mode, the flash will fire automatically in low-light and backlit conditions.

Make sure

The orange lamp in the upper right of the viewfinder lights when the shutter release button is depressed halfway.




Notes:

- When the orange lamp is blinking, the flash is being recharged and the shutter release button won't release. Release your finger from the shutter release button, and wait for several seconds.
- Maximum distance is about 70% of the distance shown left when using positive color film.

ISO	W (38 mm)	T (105 mm)
100	0.6~4.7 m (2~15.4 ft.)	0.6~2.4 m (2~7.9 ft.)
200	0.6~6.6 m (2~21.7 ft.)	0.6~3.3 m (2~10.8 ft.)
400	0.6~9.4 m (2~30.8 ft.)	0.6~4.7 m (2~15.4 ft.)

☆ **Flash Working Range (with color negative film)**

AUTO-S (Redeye Reducing Flash)




Significantly reduces the phenomenon of "red-eye" (when a subject's eyes appear red in flash photography).

In the Auto-S Flash mode, the camera will emit a series of low-power pre-flashes before the regular flash. This makes the subject's pupils contract, significantly reducing red-eye. Except for the pre-flashes, this mode is the same as the Auto Flash mode.

Redeye-Reduction may not be effective when the subject.

1. Is not looking at the flash from the right front.
 2. Is not watching the pre-flashes.
 3. Is too far from the camera.
- Does not respond to the pre-flashes due to particular individual characteristics.

IMPORTANT: Be sure to hold the camera still until the shutter releases. It takes about one second.




OFF (Flash Override)

In the Flash-OFF mode, the flash does not fire even in low-light conditions.

Use this mode in situations where flash photography is not desired or is prohibited or in twilight or night scenes.

Note: Since a slow shutter speed (down to 4 seconds) is automatically selected in low-light situations when in the Flash-OFF mode, the use of a tripod is recommended to prevent blurred pictures caused by shaking the camera. When the power switch is turned OFF, the mode will return to the AUTO mode.

FILL-IN (Forced Activation)



In the FILL-IN Flash mode, the flash fires regardless of available light.


For example, this mode can be used to brighten up a subject's shaded face or under artificial lighting such as back-lit, fluorescent light. Use this mode within the flash working range (p. 31).

It may be hard to work under the excessively bright light.

When the power switch is turned OFF, the mode will return to the AUTO mode.

NIGHT SCENE

To Capture a Night Scene Beautifully





Use the Night-Scene Flash mode to properly light subject in the foreground while leaving the background naturally lit.

Note: Since a slow shutter speed (down to 4 seconds) is automatically selected in low-light situations, use a tripod to prevent blurred pictures caused by camera shake.





Night-Scene mode cannot be used together with Spot mode.

When the power switch is turned OFF, the mode will return to the AUTO mode.



SPOT MODE

TO FOCUS AND SET THE EXPOSURE FOR A SELECTED AREA



1. Press the /REMOTE button and flash mode button at the same time,  is displayed on the LCD panel. Press the /REMOTE and the flash mode buttons at the same time or turn the power switch OFF to cancel the Spot mode.
2. Position the autofocus mark  on your subject, and press the shutter release button halfway.

Make sure

The green lamp lights,
The exposure will be locked in the center of the autofocus mark.

SELFTIMER

To Put Yourself In the Picture



1. Press the  button.  is displayed on the LCD panel.

(Make sure)

Use a tripod to hold the camera securely.


2. Aim at your subject, and press the shutter release button.


① 10 sec.: Selftimer indicator lights

② 2 sec.: Blinks

The shutter will be released about 12 seconds after the shutter release.

Notes:


- The focus and exposure will be locked when the shutter release button is depressed halfway.
- The selftimer is disengaged when the shutter is released.
- To cancel the selftimer after it has been activated, press the  button again.




REMOTE CONTROL (optional)

The optional RC 200 Remote Control is required in the operation below

1. Press the  button.  is displayed on the LCD panel.

After shooting, press the  button again to cancel the selftimer/remote control mode. Remote control operation is canceled automatically when not in use for more than about 20 minutes.



2. Aim the remote control at the camera, and press the button. The shutter will be released after about 3 seconds.

Notes:

- Use the remote control within the range shown at left.
- The camera will focus on the subject directly in front of it.
- The remote control may not work when the subject is backlit. In this case, use the selftimer.
- The remote control may not work when there is inverted fluorescent light near the camera.


CORRECTING THE DATA



1. Press the MODE button for two seconds or longer.

The year indication will start blinking.



2. Press the SET button to correct the year.

If you press the button once, the number on the display will advance by 1. And if you keep it pressed, the numbers will run in rapid succession.





3. Press the MODE button again.
The month indication will start blinking.





4. Repeat steps 2 and 3 to set the hour and minutes.

Note: As you press the mode button, the blinking indication changes in the order of year, month, day, hour, and minute. The data correction will be finished when the mode button is pressed again.

PRINTING THE DATE AND TIME

Choose the desired mode with the MODE button.

The mode will switch in the described order by pressing the MODE button.




The quartzdate uses the same power source as the main unit. Make sure to correct the data after the battery is replaced.

The data is imprinted in the lower right of the picture. If there is something whitish or tinged with orange where the data is imprinted, the data may be difficult to read. The data may not be imprinted correctly on the frame(s) after the specified final exposure of the film.

- ① No data ② Year-month-day ③ Month-day-year
④ Day-month-year ⑤ Day-hour-minute





QUESTIONS AND ANSWERS

- Q: How long will the battery last?
A: A new 3V lithium battery will last for roughly 15 rolls of 24-exposure film on which the flash was used on half of all the shots (determined under Olympus test conditions). If you do not use the flash and zoom very often, the battery will last much longer.
- Q: Why does the flash get hot?
A: If the flash is used continuously, it may become hot. If this happens, stop using the camera for a while.
- Q: Can I use infrared film?
A: No, you cannot.
- Q: How should I clean the lens?
A: Wipe the lens gently with lens cleaning tissue that has been moistened with a small amount of lens cleaning fluid.
- Q: Can I mount a filter or hood?
A: No, you cannot.
- Q: What should I do when both the orange and green lamps are blinking and the camera doesn't work?
A: Release your finger from the flash.



CARE AND STORAGE

Do not leave camera in any place exposed to excessive heat, humidity, or direct sunlight —for example, in a car on (n)n5(a)-43()-the5(a)-43()-beac



5. Do not leave the camera on or near a television, refrigerator, or other appliance with a magnetic field.

6. Do not expose the camera to dust or sand as this could cause serious damage.

7. Do not shake or shock the camera.

8. Do not apply excessive force to the zoom lens.




- Please keep the camera in a well-ventilated place.
- Do not expose the camera to extreme heat (over 40°C/104°F) or to extreme cold (below -10°C/14°F). Low temperatures, even within this range, may sometimes cause deterioration in battery performance, temporarily disabling the camera.
- Some airport X-ray machines can damage the film in your camera. Try to avoid passing your camera through these machines. Give it to the security officer for manual inspection.



- When transporting the camera from a cold place to a warm place or in the event of a sudden temperature change, put the camera into a plastic bag. This allows the camera's temperature to change slowly. Once the camera has adjusted to the new temperature, you can remove it from the bag and use it.
- Keep your hair, hands, strap etc. away from the autofocus window, lens, AE sensor and flash.
- Avoid leaving the camera unused for long periods of time. This can cause mold to grow on the camera as well as other problems. Try to press the shutter release button and check the operation of camera before use.
- This camera is controlled by a microcomputer. Problems with the microcomputer can affect or stop camera operation. If this happens, remove the batteries, then reload them and try the camera again. Strong electrical fields can also interfere with the operation of this camera so try to avoid places or objects that generate such fields.
- This camera is not suitable for professional use or for use under severe conditions.
- Strongly rubbing the leather parts with alcohol can remove the color.

CARING FOR YOUR WEATHERPROOF CAMERA

This camera is weatherproof; however, it is not designed for underwater use. Please note the following warnings and use the camera correctly.

- ① The camera can withstand splashing water (e.g., seaside, swimming pool side, etc.)
- ② The camera can be used in rain.
- ③ And in snow.
- ④ Do not wash the camera.





⑤ Do not submerge the camera or attempt to take pictures underwater.

⑥ Rubber gaskets are located inside the rear of the camera. Check the gaskets for wear and carefully remove any sand and dust to maintain a weatherproof seal.

- If the camera has been splashed by water, etc., clean the camera with a dry cloth as soon as possible.
- Do not touch the rubber gasket on the battery compartment cover or the rubber gasket on the camera back with excessive force. Do not remove the gaskets.
- Gaskets should be replaced after approximately three years, although they may require replacement earlier than that depending on use and wear.
- If the gaskets are damaged or need replacement, contact your nearest Olympus service center.

BATTERY HANDLING

NOTES

- When the camera is not used for an extended period of time, remove the battery.
- Keep spare battery on hand when going on a long trip or to a cold area.
- Sweat, oil, and so on can prevent a battery's terminals from making electrical contact. To avoid this, wipe both terminals before loading battery.
- Used batteries should be treated as general waste in accordance with local government regulations.

WARNINGS

- NEVER TRY TO DISASSEMBLE, RECHARGE, OR SHORT CIRCUIT BATTERY. NEVER EXPOSE BATTERY TO EXCESSIVE HEAT OR OPEN FLAMES.
- KEEP THE BATTERY OUT OF THE REACH OF CHILDREN. IF A CHILD SWALLOWS A BATTERY, CONTACT A DOCTOR IMMEDIATELY.
- USE ONE 3V LITHIUM BATTERY (DL123A OR CR123A). NEVER TRY TO DISASSEMBLE OR MODIFY ANY BATTERY OR BATTERY PACK FOR USE IN THIS CAMERA.

REMOTE CONTROL (optional) HANDLING

- Keep the remote control out of the reach of children. If a child swallows the remote control, contact a physician immediately.
- Never try to disassemble the remote control. Never expose the remote control to excessive heat or open flame.

TROUBLESHOOTING

OPERATING PROBLEMS

The camera does not work.

- ① The power switch is not turned ON.
→ Turn the power switch ON. (p. 20)
- ② The alignment of the battery terminals is not correct.
→ Reload the battery correctly. (p. 13)
- ③ The battery is exhausted.
→ Replace the battery with new one. (p. 14)
- ④ The battery is temporarily unable to function because of cold.
→ Keep the camera warm while using it.
- ⑤ The loaded film has been rewound.
→ Remove the film. (p. 28)
- ⑥ The film is incorrectly loaded.
→ Reload the film. (p. 17)
- ⑦ The flash is held with your finger.
→ Release your finger.

The LCD display goes off suddenly.

- ① If you don't use the camera, the LCD goes off after four and half minutes.
→ Turn the power switch OFF and then ON again or operate the zoom lever to turn the LCD back on. In addition, the power is turned OFF automatically after 4 hours. When the camera is not in use, try to keep the power switch OFF.

The shutter release button doesn't release when the remote control's shutter release button is pressed.

- ① The remote control hasn't been used in the 20 minutes since the Selftimer/Remote Control mode was engaged, causing the LCD panel to turn off.
→ Press the zoom lever. The LCD will light. Then press the Selftimer/Remote button again.

The green lamp blinks, and the shutter release button will not release.

- ① The camera is closer than 0.6 m (2 ft) to the subject.
→ Move the camera back to distance more than 0.6 m (2 ft) from the subject. (p. 24)

The orange lamp blinks, and the shutter release button will not release.

- ① The flash has not been recharged yet.
→ Remove your finger from the shutter release button and wait for several seconds until the flash is recharged before shooting. (p. 31)

The flash does not fire, even in the dark.

- ① The flash mode is set to OFF.
→ Set it to a mode other than OFF. (p. 29)
- ② High sensitivity film is being used.
→ Set the flash mode to FILL-IN. (p. 29)

The viewfinder is out of focus.

① Diopter dial is not adjusted.

→ Adjust the diopter dial until image is clear. (p. 9)

PROBLEMS WITH PRINTED PICTURES

The picture is out of focus.

① The camera moved when the shutter release button was pressed.

→ Hold the camera correctly and press the shutter release button gently. (p. 15)

② The subject was not within the viewfinder's autofocus mark.

→ Position the subject in the center of the autofocus mark, or use the focus lock. (p. 25)

③ The lens and autofocus windows were dirty.

→ Clean the lens and autofocus windows.

- ④ The autofocus window was blocked, such as by a finger.
→ Hold the camera correctly, keeping your fingers clear of the autofocus windows. (p. 15)
- ⑤ The subject was closer than the minimum working distance to the lens (0.6 m / 2 ft).
→ Shoot from more than 0.6 m (2 ft) away from the subject. (p. 24)
- ⑥ When using the selftimer, the shutter release button was pressed while standing right in front of the camera.
→ Do not stand in front of the camera. Press the shutter release button while looking through the viewfinder. (p. 37)

- ⑦ The autofocus didn't work correctly. There are some subjects that are difficult for the autofocus to lock on. These include: glossy or reflective surfaces, black objects, subjects behind glass or wire mesh, flames and smoke, excessively bright light within the picture area.
→ Focus on an object located at the same distance as the subject, then return to the subject and take the picture. (p. 26)

The picture is too dark.

- ① The flash was blocked, (e.g. by a finger).
→ Hold the camera correctly, keeping your fingers clear of the flash. (p. 15)
- ② The subject was out of the working range of the flash.
→ Shoot within the flash working range. (p. 31)
- ③ The flash mode was set to OFF.
→ Check the flash mode before shooting. (p. 30)

The data has not been printed (or looks faded).

- ① The data mode was set to no data (—).
→ Change the data mode to another setting.
(p. 42)
- ② There is a bright color like white, orange, or yellow in the area of the picture where the data is printed.
→ Avoid bright colors in the lower right corner of your photo compositions. (p. 42)
- ③ The picture was taken with black-and-white film.
→ Do not use black-and-white film if you want to print data on the pictures.
- ④ The camera's battery is low.
→ Replace with a new battery. (p. 13)


The color of a picture taken indoors is abnormal.

- ① The color of the room lighting affected the picture.
→ Set the flash to FILL-IN mode.

SPECIFICATIONS

Type: Full automatic 35 mm autofocus lens-shutter camera with built-in 38 ~ 105 mm zoom lens.
Film format: 35 mm standard DX-coded film (24 x 36 mm)
Lens: Olympus lens 38~105 mm F4.5 ~ 8.9, 6 elements in 5 groups.
Shutter: Programmed electronic shutter.
Viewfinder: Real image zoom viewfinder (with autofocus mark, close-up correction marks, autofocus indicator and flash indicator).
Focusing: Active-type autofocus system. Focus lock possible.
Focusing range: 0.6 m (2ft) ~ ∞ (infinity).
Exposure control: Programmed automatic exposure control, 3-zone light metering, switchable to spot metering. Auto exposure range: Wide-angle — EV2.3 (F4.5, 4 sec.) to EV16 (F10.9, 1/500 sec.), Telephoto — EV4.3 (F8.9, 4 sec.) to EV17 (F19.7, 1/350 sec.).

Exposure counter: Progressive type with automatic reset, displayed on LCD panel.
Selftimer: Electronic selftimer 12-sec. delay.
Remote control (optional): Infrared remote control unit with 3-sec. delay.
Film speed range: Automatic setting with DX-coded film with ISO 50, 100, 200, 400, 800, 1600, 3200. For non DX-coded film and film with less than ISO 50, film speed is set to ISO 100.
Film loading: Automatic loading. (Automatically advances to first frame when back cover is closed.)
Film advance: Automatic film winding.
Film rewind: Automatic film rewind (automatic rewind activation at end of film, automatic rewind stop). Rewind possible at any point with Mid-roll rewind button.

Flash: Built-in flash. Recycling time: Approx. 0.5 ~ 7 sec. (at normal temperature with new battery).
Flash working range: Wide-angle — 0.6 ~ 4.7 m (2 ~ 15.4 ft), Telephoto — 0.6 ~ 2.4 m (2 ~ 7.9 ft) with ISO 100 color negative film: Wide-angle — 0.6 ~ 9.4 m (2 ~ 30.8 ft). Telephoto — 0.6 ~ 4.7 m (2 ~ 15.4 ft) with ISO 400 color negative film.
Flash modes: AUTO (Automatic flash activation in low-light and backlight), AUTO-S (Redeye-Reducing, otherwise same as Auto), OFF (No flash), FILL-IN (Forced activation),  (for night scene with slowest shutter speed of 4 sec. Other functions operate as the same as in Auto mode.)
Battery check: Displayed on LCD panel.

Weatherproof: IEC Standard publication 529.

Classification of degrees of protection provided by enclosures. Degree of protection indicated by the second characteristics numeral 4.

Shot description: Protected against splashing water.

Definition: Water splashed against the enclosure from any direction shall have no harmful effect.

Test for second numeral 4: The equipment is splayed from all practical directions.

The water pressure is adjusted to give a delivery rate of 10 lit./min. The test duration shall be 1 min. per m² of calculated surface area of the enclosure with a minimum duration of 5 min.

Power source: 3 V lithium battery (DL123A/CR123A)

Dimensions: 121(W) x 66 (H) x 46 (D) mm (4.8 x 2.6 x 1.8 in) (without protrusions).

Weight: 255 g (9.0 oz)(without battery)

SPECIFICATIONS FOR DATE UNIT

Imprinting direction: Data imprinted onto film from lens side.

Data coding: No data, year-month-day, month-day-year, day-month-year and day-hour-minute.

External indication of data: Data display on LCD panel.

Film speed setting: Automatic film speed setting.

Automatic calendar system: Up to year 2030.

Power source: Ordinarily used with camera body.

SPECIFICATIONS ARE SUBJECT TO CHANGE
WITHOUT ANY NOTICE OR OBLIGATION ON THE
PART OF THE MANUFACTURER.

OLYMPUS®

OLYMPUS OPTICAL CO.,LTD.

San-Ei Building, 22-2, Nishi Shinjuku 1-chome, Shlnjuku-ku,Tokyo, Japan.Tel. 03-3340-2211

OLYMPUS AMERICA INC.

Two Corporate Center Drive, Melville, NY 11747-3157, U.S.A. Tel. 516-844-5000 /(800)622-6372

OLYMPUS OPTICAL CO.(EUROPA) GMBH.

(Premises/Goods delivery) Wendenstrasse 14-16,20097 Hamburg, Germany. Tel. 040-237730
(Letters) Postfach 10 49 08,20034 Hamburg, Germany.

OLYMPUS OPTICAL CO.(U.K.) LTD.

2-8 Honduras Street, London EC1YOTX, United Kingdom. Tel. 0171-253-2772

0197.10MM